
Instruction of Remote Control Unit

Focus control (Near & Far) when controlling Camera

FAR key for (-) & NEAR key for (+) when setting the screen menu



TELE key for Scroll-up & Wide key for Scroll-down when setting the screen menu


TELE & WIDE Zoom Control

when controlling Camera

Make sure to press a desired **camera ID# key** and **PROG key** to begin to control the connected camera

EPC-300

Cable Connection (Up to 39 Cameras)



Insert batteries into the wireless remote control unit and make sure to press a desired **camera ID# key** and **PROG key** to begin to control the connected camera

